

PAGE®

paceworldwide.com

Operation and Maintenance Manual for ST35 Soldering System

Manual 5050-0606
Rev. Date 6/14/2022



This manual applies to:

Model	Firmware Revision	Required Power	Part Number
ST35 w/PS-90 Iron	1-2	120 VAC	8007-0599
ST35 w/PS-90 Iron	1-2	230 VAC	8007-0600

TABLE OF CONTENTS

General Information.....	1
Introduction	1
Specifications	1
Temperature Specifications	1
EOS/ESD Specifications	1
Power Supply Features.....	2
Safety Guidelines	2
System Set-Up.....	3
Handpiece Connection.....	3
System Power	3
Setup and Operation	3
Operation	4
Tip Offset.....	4
LED Display - Normal Operation.....	4
Digital Control Indicator LED.....	4
Temperature Adjustment Display Mode	5
Default Factory Settings.....	5
Customizing Your System	5
Entering Set-Up Mode	6
Password	6
Temperature Scale	6
Temperature Limits	6
Automatic Setback Timer	7
AutoOff	7
Exiting Set-Up Mode	7
Corrective Maintenance	8
Display Message Codes.....	8
Power Source.....	8
Spare Parts.....	8
Service	8
PACE LIMITED WARRANTY STATEMENT	9

General Information

Introduction

Thank you for purchasing the ST35 Soldering System. This manual will provide the information necessary to properly set up, operate, and maintain your new system. Please read this manual thoroughly before using the system.

The ST35 system is offered in either 120 VAC or 230 VAC versions. Each of these incorporate SensaTemp® technology. The 230 VAC version systems bear the CE Conformity Marking, which assures the user that it conforms to EMC 89/336/EEC. All models featured in this manual are lead free compatible and comply with RoHS and WEEE directives.

This system meets the ANSI requirements for Soldered Electrical and Electronic Assemblies, J-STD-001. Additionally, it will meet or exceed the requirements for electrostatic discharge set forth by ANSI/ESD S20.20. Compliance with both standards is ensured by testing up to 50 MHz using the methodology described in ANSI/ESD S13.1 2015.

Specifications

Input Power Requirements	For 120V systems, 97-127 VAC at 50/60 Hz, 80W
	For 230V systems, 197-253 VAC at 50/60 Hz, 80W
Dimensions	104 mm H x 130 mm W x 152 mm D 4.1" H x 5.1" W X 6" D
Weight	2.3 kg (5 lbs)
RoHS Compliant	Yes
Control Technology	SensaTemp®
Tip-to-Ground Resistance	2 Ohms or less
Temperature Accuracy	Meets or Exceeds ANSI/J-STD-001
Temperature Range	38-482°C (100-900°F)


Temperature Specifications

Tip Temperature Range of 38 to 482°C (100 to 900°F).
Digital Readout Resolution: ±1° (°C or °F)
Tip Temperature Stability: ±1.1°C (2°F) while at idle.
Temperature Accuracy: Meets or exceeds ANSI/J-STD-001

EOS/ESD Specifications

Tip-To-Ground Resistance: Less than 2 ohms.
AC Leakage: Less than 2 Millivolts RMS from 50 Hz to 100 MHz.
Transient Level: Less than 500 mV peak, out to 100 MHz.

Power Supply Features



	Feature	Description
A	Program button	For access to program menu, presets, and confirmation of settings.
B	Power switch	On/off control of power supply.
C	Up arrow button	Increase set temperature and scroll through program menu functions.
D	Down arrow button	Decrease set temperature and scroll through program menu functions.
E	Power Receptacle	Front panel connection of handpiece.
F	Digital Control LED	Indicates status of power supply.
G	Display	Displays temperature setting and menu functions.
H	Ground jack	For ground system to static safe work area.
I	Power inlet with fuse	Connection for IEC power cord and fuse replacement/storage.

Safety Guidelines

The following are safety precautions that personnel must understand and follow when using or servicing this product.

1. **POTENTIAL SHOCK HAZARD** - Repair procedures on PACE products should be performed by qualified service personnel. Line voltage parts may be exposed when the equipment is disassembled. Service personnel must avoid contact with these parts when troubleshooting the product.
2. Tips and Heaters are hot when the handpiece is powered on and will remain so for a period of time after power off. **DO NOT** touch the heater or the tip. Severe burns may result.
3. PACE Tip & Tool Stands are designed specifically for use with the associated handpiece and houses it in a manner that protects the user from accidental burns.
4. Always use PACE systems in a well-ventilated area. Fume extraction systems, such as those available from PACE, are highly recommended to help protect personnel from solder flux fumes.
5. Exercise proper precautions when using chemicals (e.g., solder paste or flux). Refer to the Material Safety Data Sheet (MSDS) supplied with each chemical and adhere to all safety precautions recommended by the manufacturer.
6. **WARNING** - The handpiece must be placed into the stand when not in use.
7. This equipment is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the equipment by a person responsible for their safety.

System Set-Up

Set up the ST35 system by doing the following.


1. Remove the unit from its shipping container. Store the shipping container(s) in a convenient location. Reuse of these containers will prevent damage if you ship or store the system.
2. Place the unit on a convenient workbench.
3. Ensure the POWER Switch (located on power source front panel) is in the "OFF" or "0" position.
4. Inspect all system components, check for shipping damage, and ensure that all purchased components (standard and optional) are present.
5. Assemble Tip & Tool Stands. Attach to the power source if desired using included hardware. Assembly instructions are enclosed with each Tip & Tool Stand.

Handpiece Connection

The ST35 is designed to work with the SensaTemp PS-90 Soldering Iron or any other of the SensaTemp hand tools that do not need air pressure or vacuum to function. **Caution:** Using handpieces from other product lines (e.g., IntelliHeat, AccuDrive, HeatWise) may result in damage to your new equipment.

Connect the handpiece connector to the Power Receptacle in the following manner.

1. Align guide on connector with slot on power receptacle.
2. Insert connector into power receptacle.
3. Turn the connector housing clockwise to lock in place.



System Power

1. Insert the female end of the power cord into the AC Power Receptacle on the rear panel of the power source.
2. Plug the prong end (male end) of the power cord into an appropriate, grounded AC supply receptacle.

Setup and Operation

Operation

1. Ensure the Set-Up procedure has been performed. Check the following:
 - Handpiece connection to the power source.
 - Proper Tip is installed in handpiece.
 - Power cord is connected to both an appropriate AC supply and the ST35 unit.
2. Turn the Power Switch On ("I").
3. After a brief start-up sequence, the Set Temperature will be displayed.
4. Adjust the tip temperature by pressing and holding Scroll Up (▲) Key or Scroll Down (▼) key. Observe the display as the Set Temperature increases first in increments of 1° and then in increments of 10°. When the desired temperature is reached, release the key.
5. **NOTE:** The Set Temperature can be adjusted only within the defined temperature limits. If the upper limit has been reached, the display will read "HiL"; if the lower limit is reached, the display will read "OFF". Temperature limits can be adjusted in the Set-Up menu.



Tip Offset

Differences between the temperature settings and true tip temperatures are negligible when using Thru-Hole, single point soldering tips. With any heating system however, True Tip Temperatures can differ greatly from temperature settings when using larger SMT soldering tips. Before adjusting offset, it is recommended to first check the actual temperature of the tip using a Tip Temperature Monitor.

To adjust the temperature offset, hold the Program Key (●) down for 5 seconds. The display will change to show "000". If the unit already has a Tip Offset than it will be shown in place of "000". Use the keypad (▲▼) to increase the temperature offset up to 83°C (150°F) hotter. When finished press the Program Key (●) to return to normal operation or, after 5 seconds of inactivity, the system will return to normal operation on its own.

LED Display - Normal Operation

The LED Display provides a 3-digit display of information. The display will show different things such as:

1. "888" on initial power up to ensure that all sections of the display are working.
2. The software version of the installed microprocessor (e.g., "1-9") for 2 seconds after the "888" is displayed.
3. Actual temperature of the connected handpiece, during normal operation.
4. The displayed temperature will begin blinking (the indicator LED will also turn Amber) when the unit has gone into Temperature SetBack.
5. "OFF" with stable display when the temperature set point has been adjusted beyond the Lower Temperature Limit.
6. "OFF" with blinking display when the unit has entered AutoOff mode. Refer to page 7 for more information.

Error messages "OSE" or "OCE" will appear if a system fault is detected. Refer to the "Corrective Maintenance" portion of this manual.

Digital Control Indicator LED

The colored LED on the power source front panel indicates when the handpiece is heating, has reached the set temperature, or if a fault has occurred.

LED Full On Red – A fault has occurred such as nothing is plugged into the Power Receptacle on the front of the unit or the Heater Element of the connected tool has an issue. Check installation of Heater Element on the handpiece as well as the handpiece’s connection to the front panel.

LED Full On Green – The attached soldering tool has reached the Set Temperature.

LED Full On Amber – The heater in the connected handpiece is functioning and in process of heating up to the Set Temperature or may be cooling down to the SetBack Temperature.

LED Off - Unit is not turned on or is in Auto ShutOff.



Temperature Adjustment Display Mode

The display will show the following when adjusting the desired Set Tip Temperature.

1. The Set Tip Temperature.
2. "HiL" (High Temperature Limit) when adjusting the set tip temperature and the maximum allowable temperature is exceeded. Refer to the "Set-Up Mode" portion of this manual.
3. "OFF" (Low Temperature Limit) when adjusting the set tip temperature and the minimum allowable temperature is exceeded. Refer to the "Set-Up Mode" portion of this manual.



Default Factory Settings

Your new ST35 is equipped with several features which may be adjusted by the user. Listed below are the default settings of each. To learn about any of these features, refer to the applicable section of the “Customizing Your System” in this manual.

Feature	Factory Setting
Password	None Entered
Default Temperature Scale (°C/°F)	°F for 115 VAC Systems
	°C for 230 VAC Systems
“HI” Temperature Limit	427 °C (800 °F)
“LO” Temperature Limit	260 °C (500 °F)
SetBack Timer	Enabled, 30 minutes
Auto Off	Enabled, 60 minutes
Set Temperature	371 °C (700 °F)
Tip Offset	0 °C (0 °F)

Customizing Your System

The menu driven user interface of the systems allows you to easily customize your system. In Set-Up Mode, you can:

- Enter, remove, or change a Password.
- Set the Default Temperature scale to °F or °C.
- Change the Upper and Lower Temperature limits.
- Enable the Temperature Setback feature and adjust the time-out period (if enabled).
- Enable or disable the Auto Off feature and adjust the time-out period (if enabled).

Entering Set-Up Mode

The following instructions should be performed to familiarize the operator with the system.

1. Place Power Switch in the "OFF" ("0") position.
2. Press and hold the Program Key (●) while turning the Power Switch on ("1" position). Release all keys when the software version is displayed.

Password

3. The LED Display will show the version of the microprocessor and change to read "P- -" or "EP".
 - If the display reads "EP", a Password has been stored in system memory. The password must be entered to access the menu. If the wrong password is entered, "no" will appear on the display and the system will return to normal operation. If this occurs, repeat steps 1 & 2 and enter the correct Password.
 - Once the LED Display reads "P- -". Choose one of the following options:
 - Press the Program Key (●) to keep the current password (even if there is no password) and move on to the next setting or
 - Set a 3-digit password by using the keypad (▲▼). (1 to 999). Make a note of the new password for future reference. Selecting 000 and saving the changes will clear the password to allow access without entering one. Press the Program Key (●) to advance to the next setting.



Temperature Scale

4. The display now shows the stored default Temperature Scale, either °C or °F. Choose one of the following:
 - Press the Program Key (●) to keep the stored default Temperature Scale.
 - Use the Scroll Up Key (▲) to change the default Temperature Scale.
 - Press and release the Program Key (●) to proceed to the next step



Temperature Limits

5. The display will show the stored default High ("Hi") Temperature Limit by alternating to show "Hi" and the stored limit. Choose one of the following:
 - Press and release the Program Key (●) to keep the stored High Temperature Limit.
 - Adjust the stored High Temperature Limit using the keypad. (▲▼) Cannot be adjusted below the Low Temperature Limit.
 - Press and release the Program Key (●) to proceed to the next step.



6. The display now shows the stored default Low ("Lo") Temperature Limit with the display alternating to



show "Lo" and the stored limit. Choose one of the following:

- Press and release the Program Key (●) to keep the stored Low Temperature Limit.
- Adjust the stored Lo Temperature Limit using the keypad. (▲▼)
- Press and release the Program Key (●) to proceed to the next step.

The full allowable temperature range of the ST35 is between 38°C (100°F) and 482°C (900°F). The Low Temperature Limit cannot be adjusted higher than the High Temperature Limit. These limits control how high or low the Set Temperature can be adjusted to during normal operation.

Automatic Setback Timer

To preserve tip life and save energy, the system can automatically adjust the tip temperature to 177°C (350°F) after a selectable period of inactivity (factory setting of 30 minutes). There are 3 ways to exit Temperature Setback; pressing the Scroll Up or Scroll Down keys (▲▼), flipping the power switch off then on again, or holding the tip against a damp sponge. Upon exit of the Temperature Setback, the unit will resume normal operations and the handpiece heat back up to the Set Temperature.

7. The display now shows the stored Automatic Setback time as "S-X" (x=0 thru 9). Time is shown as tens of minutes (e.g., "S-3" equals 30 minutes). A display of "S-0" indicates that Setback is disabled. Choose one of the following:



- Press and release the Program Key (●) to keep the currently stored Temperature Setback time.
- Adjust the stored Temperature Setback value using keypad. (▲▼)
- Press and release the Program Key (●) to proceed to the next step.

AutoOff

What is AutoOff? When enabled, the AutoOff safety feature turns off the power to the handpiece after a pre-selected time (between 10- 90 minutes) from the system entering Temperature Setback. When the system has entered Temperature Setback, a timer within the system circuitry will start running.

If any key is pressed during the selected time out period, the AutoOff and Setback timers are reset. The system will return to normal operation. At the end of the time out period, the system will enter Auto Off. Power is turned off to the heater and the display will show a flashing "OFF". Exiting Auto Off: Auto Off can be exited; returning to normal operation by pressing and releasing a Key (any of the 3 keys ●▲▼), or by turning the Power Switch OFF ("0") and then back ON ("1").

8. The display now shows the stored Auto Off time as "AOx" (x=0 thru 9). Time is shown as tens of minutes (e.g., "AO8" equals 80 minutes). A display of "AO0" indicates that Auto Off is disabled. Choose one of the following:



- Press and release the Program Key (●) to keep the currently stored Auto Off time.
- Adjust the Auto Off value using the keypad. (▲▼)
- Press and release the Program Key (●) to proceed to the next step.

Exiting Set-Up Mode

9. The LED Display now reads "End". The Set-Up Mode procedure is now complete. Choose one of the following steps:



- Press and release the Scroll Up Key (▲) to save the changes, exit the Set-Up Menu and return to normal operation.
- Press and release the Scroll Down Key (▼) to return to the start of the Set-Up Menu without saving any changes. Go back to step 3, Password Entry.

Corrective Maintenance

Display Message Codes

Display Message	Description
"no"	The incorrect password has been entered. The displayed message will time out after 6 seconds and revert to normal operation. Enter the correct password.
"OCE"	"Over Current Error" The Heater circuit is shorted, or the handpiece has failed. Inspect handpiece and heater element, replace as needed.
"OSE"	"Open Sensor Error" Unit is unable to sense the sensor from the handpiece. Make sure handpiece is connected. Inspect handpiece and heater element for damage or wear, replace as needed.
"OFF"	The AutoOff feature has activated, turning off the handpieces. Press any button on the unit to return to normal operation.

Power Source Issues

Most malfunctions are simple and easy to correct.

Symptom	Probable Cause	Solution
No power to system	Blown Fuse	Replace the fuse (located in the AC Receptacle Fuse Holder) with one of the same.
Handpiece not heating up	Defective Heater Element	Refer to the appropriate handpiece manual.
	Power Source Malfunction	Contact PACE

Spare Parts

Description	PACE Part Number
Fuse 1 Amp, Time Lag (for 115V)	1159-0246-P5
Fuse 0.50 Amp, Time Lag (for 230V)	1159-0213-P5
Optional under shelf mounting bracket	1321-0609-P1

Service

Please contact PACE or your local distributor for service and repair.

PACE LIMITED WARRANTY STATEMENT

Limited Warranty

Seller warrants to the first user that products manufactured by it and supplied hereunder are free of defects in materials and workmanship for a period of one (1) year from the date of receipt by such user. This Warranty as applied to blowers, motor pumps, x-ray tubes, lenses, optical/lighting probes and cameras is limited to a period of six (6) months. Monitors, computers and other brand equipment supplied but not manufactured by PACE are covered under their respective manufacturer's warranty in lieu of this Warranty.

This warranty does not cover wear and tear under normal use, repair or replacement required as a result of misuse, improper application, mishandling or improper storage. Consumable items such as tips, heaters, filters, etc. which wear out under normal use are excluded. Failure to perform recommended routine maintenance, alterations or repairs made other than in accordance with Seller's directions, or removal or alteration of identification markings in any way will void this warranty. This warranty is available only to the first user, but the exclusions and limitations herein apply to all persons and entities.

SELLER MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, AND MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Seller will, at its option, repair or replace any defective products at its facility or other locations approved by it at no charge to user, or provide parts without charge for installation by the user in the field at user's expense and risk. User will be responsible for all costs of shipping equipment to Seller or other location for warranty service.

EXCEPT FOR THE REMEDY ABOVE DESCRIBED, UNLESS OTHERWISE REQUIRED BY APPLICABLE LAW, SELLER WILL HAVE NO OTHER OBLIGATION WITH REGARD TO ANY BREACH OF WARRANTY OR OTHER CLAIM WITH RESPECT TO THE PRODUCTS, OR LIABILITY FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, OR INCIDENTAL LOSS OR DAMAGE CAUSED BY OR OCCURRING IN CONNECTION WITH ANY OF THE PRODUCTS.

Warranty service may be obtained by contacting the appropriate PACE Company or local Authorized PACE distributor as set forth below to determine if return of any item is required, or if repairs can be made by the user in the field. Any warranty or other claim with respect to the products must be made with sufficient evidence of purchase and date of receipt, otherwise user's rights under this warranty shall be deemed waived.

PACE Incorporated retains the right to make changes to specifications contained herein at any time, without notice. Contact your local authorized PACE Distributor or PACE Incorporated to obtain the latest specifications.

The following are trademarks and/or service marks of PACE, Incorporated Vass, NC USA: AccuDrive®, Arm-Evac®, Cir-Kit®, ConducTweez™, Flo-D-Sodr®, HandiPik™, IntelliHeat®, LapFlo™, Mini-Wave®, MiniTweez®, PACE®, PACE EUROPE®, PACE WORLDWIDE®, PACENTER®, Pik-Tip®, PikVac™, Redi-Rak™, ResisTweez™, SensaTemp®, SMR®, Snap-Vac®, SodrTek®, Sodr-X-Tractor®, StripTweez™, Thermo-Drive®, ThermoFlo®, ThermoJet®, ThermoPart™ ThermoPik™ and ThermoTweez®, VisiFilter™.

PACE products meet or exceed all applicable military and civilian EOS/ESD, temperature stability and other specifications including MIL STD 2000, ANSI/JSTD 001, IPC7711, and IPC A-610.



**PACE Incorporated
346 Grant Road
Vass, NC 28394**

**Tel: (877) 882-PACE
Tel: (910) 695-7223
Fax: (910) 695-1594**