



PACE Incorporated 9030 Junction Drive Annapolis Junction, MD 20701 Tel: (301) 490-9860 Fax: (301) 498-3252	PACE Europe Limited 13 Tanners Drive Blakelands, MK1 45BU Tel: (44) 1908-277666 Fax: (44) 1908-277777
--	---

www.paceworldwide.com

SX Collection Description P/N 5050-0567

Included in this pack out are two different versions of solder collection chambers one of which is made of glass, the other of cardboard and both offer distinct advantages and disadvantages depending on your type of desoldering operations.

Cardboard Filters provide an easy solution to cleaning, handling and disposal. The cardboard filters are designed as a one use, disposable item and under normal operating levels and conditions should provide the same life cycle span seen with as a glass chamber would have between cleanings. The cardboard filters are unbreakable, easy to handle and are clearly marked for ease of installation. When the filter becomes full, simply remove it, dispose in accordance with state, local and corporate regulations and replace. The main disadvantage of using this type of filter is consumable cost. If your desoldering operation is high volume, it will be necessary to replace these filter types frequently.

Glass chambers provide the benefit of re-use, keeping overall consumable costs at a minimum. For virtually any level of use the glass chamber is effective and can be easily cleaned and re-used almost a limitless number of times. The main disadvantage of using glass chambers is that if they are mishandled, they break. Care must be used when handling a glass chamber to avoid this and if handled and cleaned properly will last indefinitely.

